

Prinsu



GO PRO BRACKET



Applications installation instructions

These installation instructions apply all Prinsu roof and top racks

IMPORTANT!

THANK YOU for purchasing this Prinsu product. Please read through this entire document before proceeding with installation. If you are not confident in your mechanical skills, please seek the help of a professional to perform the installation. Check your packages immediately upon arrival to ensure that everything listed is included, and to check for damage during shipping. ***If anything is missing or damaged, or if you need technical assistance with any aspect of this installation, call Prinsu at (208) 528-0664 as soon as possible.***

IMPORTANT!

Caution:


The handling characteristics of the vehicle changes when you transport a load on top of the vehicle. For safety reasons we recommend you exercise extreme care when transporting wind-resistant loads. Special consideration must be taken into account when cornering and braking.

Note for Dealers and Installers:

It is your responsibility to ensure instructions are given to the end user or client.

Hardware 1:1 Scale View


A 1 – 1/4"-20x3/4" Carriage bolt



B 1 – 1/4" Flat Washer



C 1 – 1/4" Nylock Nut



Exploded Product/Hardware View



Questions?

Call: 866-522-0697

Email: info@prinsudesign.com



792 E Iona Rd.
Idaho Falls, ID 83274
prinsudesignstudio.com
208.528.0664