



3RD GEN TACOMA

Ditch Light Bracket

installation instructions



• Hardware

No hardware included with these brackets. You will reuse the factory hood hinge hardware.

• Installation

Open hood and secure with hood support rod

Starting on one side (either passenger or driver's side) remove farthest forward bolt. (Photo A) Insert DLB as shown in picture. Run bolt in until the DLB will just swing out of the way of the rearward bolt. (Photo B)

Remove rearward bolt and swing DLB so holes line up and insert bolt. Snug down both bolts making sure the hood hinge is seated in the same position it was before. (Photo C)

Move to the other side and repeat steps 1 through 3.

**** CAUTION DO NOT CLOSE HOOD YET!!!**

Carefully close the hood and check the gaps to make sure they are even and that the hood has not shifted. (Photo D)

If they have shifted loosen the hinge bolts and adjust the hood for correct gaps.



For questions or further help:

Call: 866-522-0697

Email: info@cbioffroadfab.com